

Fig. 1




Fig. 2




Fig. 3

VLR / MSC

Mobile terminal
enters area of
VLR

HLR

SCF

201

Update Location & Insert
Subscriber Data messaging

202

Mobility Management Event Notification
(Notification that user attached to network)

204

Cancel Location message

Subscriber deactivated 203

Mobile detached
from network

301

Note Subscriber Data Modified message
(Notification that subscriber deactivated)

Register updated




Fig. 4




Fig. 5

VLR / MSC

SIM card
replaced

401

HLR

User information
updated

402

SCF


501

Service information, for user with IMSI 11222666

502

Error message

Fig. 6



NoteSubscriberDataModified

7 / 8

702

Fig. 8

Procedure CAMEL_NSDC_HLR

/* Procedure in the HLR to notify the gsmSCF about a change in subscriber data. */

1(1)

/* Signals to/from the left are to/from the gsmSCF. */

